

## Using Microsoft Word on a PC

### To embed your fonts in Microsoft Word 2010:

1. Create your manuscript using a TrueType font. Recommended fonts include Times-Roman and Helvetica.
2. In the File pull-down menu click on Options.
3. Choose Save on the left sidebar.
4. Check the box next to Embed fonts in the file.
5. Click the OK button.
6. Save the document.

### To embed your fonts in Microsoft Word 2007:

1. Create your manuscript using a TrueType font. Recommended fonts include Times-Roman and Helvetica.
2. Click the circular **Office button** in the upper left corner of Microsoft Word.
3. A new window will display. In the bottom right corner is a button, Word options. Click the **Word Options** button.
4. Choose **Save** from the left sidebar.
5. Check the box next to **Embed fonts in the file**.
6. Click the **OK** button.
7. Save the document.

### To embed your fonts in earlier versions of Microsoft Word:

1. Create your manuscript using a TrueType font. Recommended fonts include Times-Roman and Helvetica.
2. On the **Tools** menu, choose **Options**
3. Click the **Save** tab.
4. Select the **Embed TrueType fonts** check box.
5. Save the document.

## **Using Microsoft Word on a Mac**

Microsoft Word 2008 on a Mac OS X computer will automatically embed your fonts while converting your document to a PDF file.

*Please note that previous versions on Microsoft Word on a Mac are not able to embed fonts.*

Another option you might consider is using OpenOffice (which embeds fonts automatically while converting to PDF) or using a PC to embed fonts in your manuscript.

## Using Adobe Acrobat Professional

Alternatively, if you have Adobe Acrobat Professional available to you, you can follow the excellent instructions provided by the Graduate Thesis Office at Iowa State University:

1. Open your document in Microsoft Word.
2. Click on the Adobe PDF tab at top. Select Change Conversion Settings.
3. Click on Advanced Settings.
4. Click on the Fonts folder on the left side of the new window. In the lower box on the right, delete any fonts that appear in the Never Embed box. Then click OK.  
If prompted to save these new settings, save them as "Embed all fonts."
5. Now the Change Conversion Settings window should show "embed all fonts" in the Conversion Settings drop down list and it should be selected. Click OK again.
6. Click on the Adobe PDF link at the top again. This time select Convert to Adobe PDF. Depending on the size of your document and the speed of your computer, this process can take 1-15 minutes.
7. After your document is converted, select the File menu at the top of the page. Then select Document Properties.
8. Click on the Fonts tab. Carefully check all of your fonts. They should all show "(Embedded Subset)" after the font name.
9. If you see "(Embedded Subset)" after all fonts, you have succeeded.